MTCE-10R-NT   *MTCE-10T-NT*

1.1 Appearance and terminal





3.1 Ambient temperature

3.2 Installation site

3.3 Installation method

4.1 Terminal introduction



⏚	

4.2 Wiring



Wiring Requirements

Display Area

5.1 Power-supply Specification

5.2 Performance Specification

≤ ≤

×

h00 @

– – –